



This doc is about to install or re-install the driver for Card Writer, the one used in HDL hotel system.

Step1: plug in the USB device. Find it as below and select “Update Driver Software...”



Step2:



Step3:

